





ASSEMBLY INSTRUCTIONS FOR JEWELRY ARMOIRE

ITEM: CJ-171

PARTS AND HARDWARE LIST			
NO.	Description	Q'ty	Sketch
A	TOP	1	
B	Armoire	1	
C	Wood Screw	5	
D	Screwdriver	1	

1. Carefully stand armoire upright on Legs, attached the Top (A) to the hinge at rear of the Armoire (B) with the 5 Wood Screws (C) by using Screwdriver (D).

